

TR\_readme.txt

Transducer.exe monitors the Transducers output on a Windows® PC and allows you to change pressure units on the fly from the native pressure units of the Transducer to PSI / kPa / BAR / inH2O / inHg / mmHg / FSW / kg/cm<sup>2</sup> and Atmospheres.

This program has been tested and used extensively with Windows® 2000 & XP. Its operation in Windows® 95, Vista and 7 is unknown.

Software installation instructions:

1. Create a folder within the 'Program Files' folder called 'Perma-Cal'.
2. Create a folder within the 'Perma-Cal' folder called 'Transducer'.
3. Download the TR.zip file.
4. Unzip the file to c:\Program Files\Perma-Cal\Transducer.

NOTES:

You must use the path specified above. No other will work.

This software is provided free and without any guarantee or implied warranty. Specifications subject to change without notice.

Program requirements:

This program requires the Microsoft® modules listed below be installed in the c:\windows\system32 folder. These modules are included in the TR.zip file.

mscomm32.ocx  
msstdfmt.dll  
richtx32.ocx

After installation, the modules must be registered with Windows®. To register click on 'Start', Select 'Run' and enter the following:

regsvr32 c:\windows\system32\ ... omit ( ) around the module name

NOTE: These modules are Microsoft® products so they may already be installed on your computer. Search the c:\windows\system32 folder to verify.

To remove the program:

Since this program does not use the Windows® registry, you can simply delete the 'Perma-Cal' folder from the 'Program Files' folder and all of the program will be gone. If you wish, you can also delete the Microsoft® modules listed above. However, be careful, since these are standard Microsoft® products, other programs on your computer may use them.

Updated June 16, 2011